



VORTEX

TECHNICAL SUPPORT
system@vortexgear.tw

CUSTOMER SERVICE
vortexkeyboard.cs@gmail.com

OFFICIAL WEBSITE
www.vortexgear.store



Connection 2.4Ghz / Bluetooth

- 2.4Ghz Mode (Left)
- Wired Mode (Center)
- Bluetooth Mode (Right)

Step 1 -----> **Fn** + **Home**

Step 2 -----> Press **PgUp** or **PgDn** or **End**
Device 1 Device 2 Device 3

Switch between paired devices

Fn + **PgUp** or **PgDn** or **End**
Device 1 Device 3 Device 3

Bluetooth switch on, press Fn+Home to enter pairing mode until LED_A is solid blue and then release, hit directly press any of the three bluetooth bottoms to start pairing (the LED_A flashes Blue light and the device will show "PC66" or "PC68" depends on number of keys on your keyboard, click OK to connect); pairing completed, the LED_A goes out.

- The power switch switches the device, the LED_A indicator flashes once, indicating that the battery compartment is powered normally. (Blue for bluetooth, Green for 2.4Ghz)
- When the Bluetooth/2.4Ghz is turned on and paired, the LED_A Blue/Green flashes at 3Hz; if it is not connected for 3 minutes, it will be stopped.
- Low power: 2.2V low power alert. (LED_A Red, 1-second flashing indication)
- When the power switch is turned from OFF to ON, it will remember the wireless device before OFF.
- In 2.4Ghz/Bluetooth mode, if the keyboard is inoperative for 1 minute, the lighted indicator will be turned off automatically, press any key to light up. If the keyboard is not operated for 30 minutes, it will go into hibernate mode.

Battery : AAA / 1.5V *2 (Alkaline battery)
Working Current : 9mA — Release the key for 5 seconds will enter into standby mode
Standby Current : 5mA — Standby for 5 seconds will enter into hibernation mode
Hibernation Current : 0.7 ~ 1mA — Hibernate for 30 minutes will enter into sleep mode
Sleep Current : 0.7mA (Bluetooth will be disconnected)
Rated Input Power : 5V = 500mA

LED_A Indicator
(At Caps Lock position)



Product Name : Mechanical Keyboard
Model Name : VTK-6800
Product Size :
L*W*H : 33.0*16.5*3.5 cm ± 0.3

Qwerty Key



Dvorak Key



Colemak Key



Fn Key Combos

- Fn** +
- Esc** = `
 - Shift + Esc** = ~
 - 1 !** = F1
 - 2 @** = F2
 - 3 #** = F3
 - 4 \$** = F4
 - 5 %** = F5
 - 6 ^** = F6
 - 7 &** = F7
 - 8 *** = F8
 - 9 (** = F9
 - 0)** = F10
 - _ =** = F11
 - = +** = F12
 - Backspace** = Delete
 - ;** = Insert
 - P** = Print
 - [{** = Scroll
 -]** = Pause
 - A** = Previous
 - S** = Play / Pause
 - D** = Next
 - F** = Mute
 - H** = Volume +

- G** = Volume -
- I** = Up
- J** = Left
- K** = Down
- L** = Right
- ?** = 66key: Menu
68key: Windows
- >** = Windows_R
- Z** = 66key: Windows
68key: Menu
- Win** = 68key: Winlock
LED_A Cyan(G+B)
- Spacebar** = Capslock
- Alt_L/R+PgUp press 2s** = Colemak
- Alt_L/R+PgDn press 2s** = Dvorak
- Alt_L/R+End press 2s** = Qwerty
Switch key layout
LED_A flashes white color
- Alt_L/R+HOME press 2s** = Switch O.S
Mac O.S / Windows O.S
LED_A flashes white color
- Alt_L+Alt_R** = Keyboard restore to default
Hold on for 3s, LED_A flashes white color for 3s

RGB Light Setting

(Only available in wired mode of RGB version)

If you want to switch the lighting mode, please turn on the backlight.

Lighting Mode : Spin / Breath / Single light / Ripple / Wave / Lighting steady / Off
Single Color Mode : White / Green / Cyan / Blue / Purple / Pink / Orange / Red / Yellow

- Fn** +
- Alt_L** = Switch lighting mode
 - Ctrl_L** = Switch color
 - Up** = Brightness up, 5 levels
 - Down** = Brightness down, 5 levels
 - Right** = Speed up, 5 levels
 - Left** = Speed down, 5 levels

Company Name : Vortexgear Co., Ltd.
Company Address : 4F., No. 14, Ln. 181, Sec. 2, Jiuzong Rd.,
Neihu Dist., Taipei City, 11470, Taiwan